

Party Amarillo, LLC

Criss-Cross Collision

How to inflate and deflate the balls

TO INFLATE THE BALLS:

- Plug the vacuum into a 20 amp circuit. Place the hose to the vacuum in the “inflate” port.
- You can unplug the cord to the motor for the Criss-Cross inflatable to gain access to electricity. Then plug the Criss-Cross back after the balls are inflated.
- Unfold the ball and locate the 2 inflation ports located by the black handles.
- Unscrew both parts to the valve.
- Hold the ‘inflation tip” tightly to the valve located on the ball.
- After the ball is almost inflated, screw in the bottom part of the plug and continue to inflate.
- After the ball is completely filled, but not overfilled, screw the plug into the valve.
- Repeat process with the second inflation port.

TO DEFLATE THE BALL

- Open both valves and allow the balls to deflate. To complete deflation you will use the vacuum.
- Move the hose to the “deflate” side of the vacuum.
- Place the hose over the valve of the ball and turn on the vacuum.
- The vacuum will remove the remaining air so the balls will fit into the bags.
- Roll up each ball and place into the bags provided.
- Please notify Party Amarillo if any damage has occurred to the balls.

TROUBLE SHOOTING:

- The Balls will not hold air:
Check for holes in the balls.
- You can also apply duct tape to the balls if necessary.
- Holes will occur in the balls, if they are used around sharp gravel, stickers, or other rough surfaces.

WARNING:

- Adults only should inflate the balls.
- Do not leave the vacuum unattended.
- Do not use the vacuum near moisture or other unsafe conditions.