

Party Amarillo, LLC

Criss-Cross Collision

ATTENDANTS READ HERE:

1. Two or three adult attendants must supervise the unit. Do not leave the unit unattended at any time.
2. The attendants must read and understand the safety instructions and are responsible to make all riders aware of the safety rules. Safety of the riders is the responsibility of the attendants.
3. Deflate immediately if high wind, rain, lightning, or thunder is present or approaching.
4. The inflatable must be securely staked at all times.
5. Place only **one** racer inside each giant ball. Caution: Keep the track free from spectators.
6. The racers should race to the end of the track, turn around and come back to the starting area.
7. Attendants must help the racers to stop at the end of the track so they do not roll off the end.
8. Do not allow the racers to use the giant balls outside the race track at any time.
9. The balls must always be used on a flat area. Do not set up the track on a slope.
10. Do not allow anyone to participate who is intoxicated, pregnant, or has any other physical limitations, including neck, back, knee, or other disabilities that may jeopardize their safety.
11. No shoes, silly string, sharp objects, food, gum, confetti, glitter, or pets allowed.
12. Do not allow the inflatable or motor to get wet. Keep away from the blower and extension cords.

TO ASSEMBLE THE GAME:

1. The inflatable is heavy and will take 2 strong men to set up the unit. Use caution when lifting.
2. Dimensions are about 17'W x 70'L x 1'H. Allow 5' clearance on all sides, including the top.
3. Pick a flat, level location free from overhead obstacles like electrical lines or trees, and also away from the vicinity of underground utilities or irrigation. Do not use around sharp rocks or stickers.
4. The location must be less than 50 feet from a 20 amp dedicated circuit.
5. Grass is the best surface. The inflatable must be securely anchored at all times. Do not use around stickers, or other sharp surfaces.
6. Do not inflate the unit if high wind or rain is present. Watch for severe weather approaching.
7. Unroll the vinyl roll. Locate the blower tubes extending from the unit.
8. Tie one tube securely around the blower, and tie off the other tubes.
9. Make sure there are no kinks in the tubes. Make sure all zippers are closed under the Velcro flaps.
10. Plug the blower into a GFI outlet and allow the unit to inflate. Don't plug anything else into the same circuit or it will trip the breaker. (If a generator is used it must be at least 4000 Watts)
11. Use only the extension cords provided. Do not remove the grounding pin from cord.
12. If the blower is used on a gym floor, place a mat under the blower.
13. Immediately anchor the unit by inserting the stakes completely into the ground at a 90 degree angle straight into the ground.
14. The blower will run continuously during the event.
15. See Instructions located with the vacuum to inflate and deflate the balls.
16. No one is allowed in the unit or balls until it is anchored and supervised by a trained attendant.

TO TAKE DOWN THE GAME:

1. Clean all debris from the inflatable. Please inform us if the inflatable is damaged, dirty or wet.

2. Turn off and untie the blower. Allow the inflatable and ball to deflate. Remove the blower and the stakes.
3. Roll up the inflatable very tightly. It will be easier to move.
4. Use extreme caution when handling the inflatable. It is heavy and will take 2-3 men to load.