



# Cotton Candy Machine Instructions




## Setup:

- Setup Cotton Candy machine on a secure table top
- Un-tighten top 2 screws of machine (allows cotton candy head to move freely)
- Put bowl on top of machine (no screws, clamps, or locks needed)

## Making Cotton Candy:

- Turn both switches to the ON position (rotating switch and heating switch)
- Once heating switch is turned on, cotton candy sugar is heated and thrown to the sides of bowl.
- **Caution:** first 1-2 minutes of operation throws out hard sugar particles because the machine is not heated yet. Make sure everyone is standing about 3-4 feet back.
- Take cone and rotate around bowl until cotton candy has collected.



## Potential Problems:

- Make sure both switches are turned on. If heating switch is not turned on it will simply throw out hard sugar particles.
- Make sure screws are tightened or else machine will not work properly.
- Make sure electricity cord is plugged into the electricity outlet or machine will not operate.