



BOUNCE UNIVERSE PARTY RENTALS

469-600-2291

WWW.BOUNCEUNIVERSE.COM

Popcorn Machine Instructions

1. Undo machine into its own standard 15amp outlet! (Machine will need 1 - 15amp circuit)
2. Do not use an extension cord! Other than what may be provided.
3. Turn on kettle heat switch, kettle motor switch and light / warmer switch.
4. Leave doors open while popping.
5. Place oil in kettle. When oil has melted; add popcorn and seasoning.
6. When popcorn has finished popping; rotate the kettle handle to empty popcorn from kettle to upright position.
7. Repeat cycle from step 4; subsequent batches are always more flavorful than the initial batch.
8. Turn off kettle heat switch on the final batch right after you pour the corn in the kettle to prevent any odor from burning popcorn and eliminate any unnecessary smoke.
9. Turn off the kettle motor switches when you are finished.
10. Turn off all switches when you are finished.
11. Empty out popcorn and any unpopped kernels in the kernel tray prior to returning.

Consult Bounce Universe for additional equipment and accessories for you special event.



**UNDERSTAND YOUR RENTAL CONTRACT, KNOW YOUR
RESPONSIBILITY FOR THE EQUIPMENT YOU HAVE RENTED!**