Popcorn Machine Instructions



Our six ounce popcorn machine is very easy to use. Just follow these instructions to make some yummy popcorn.



Enough product is included with the rental to make up to 35 individual serving bags. Each bag contains popcorn, oil/butter flavoring and salt.



- 1. Make sure machine is plugged into a normal household 110v outlet. Do not share this outlet with other concessions or bounce houses. This could cause the breaker to pop.
- 2. Power on the unit by turning on all three switches. Let it preheat for 4 minutes.



3. Cut the top off of one of the packets, both oil and popcorn go into the kettle at the same time.



- 4. Make sure all oil is squeezed out of the packet and always remember to close the lid. Be careful of the hot edge on the kettle.
- 5. After a short time, the popcorn will begin to pop. Once popping has completed, push down on the kettles handle to dump the popcorn. At this point you can start a new batch or turn off the heat and motor switch.
- 6. Leaving the light switch on will also keep the popcorn warm with a heating element in the base of the unit.