

12403 Stark Rd, Livonia, MI 48152

T: 833-5-LITTLE

W: www.fivelittlemonkeys.fun

E: info@fivelittlemonkeys.fun

Safety & Operating Instructions

→ **IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE ATTEMPTING TO USE THIS MACHINE** ←
→ **KEEP ALL MINORS & SPECTATORS AT A SAFE DISTANCE FROM THE MACHINE AT ALL TIMES** ←

	<p>⚠ DANGER</p> <p>Machine must be properly grounded to prevent electrical shock to personnel. Failure to do so could result in serious injury, or death. DO NOT immerse any part of this equipment in water. DO NOT use excessive water when cleaning. Keep cord and plug off the ground and away from moisture. Always unplug the equipment before cleaning or servicing. Make sure all machine switches are in the OFF position before plugging the equipment into the receptacle.</p> <p>008_051514</p>
	<p>⚠ DANGER</p> <p>Improper installation, adjustment, alteration, service, or maintenance can cause property damage, injury, or death. Any alterations to this equipment will void the warranty and may cause a dangerous condition. This appliance is not intended to be operated by means of an external timer or separate remote-control system. NEVER make alterations to this equipment. Read the Installation, Operating, and Maintenance Instructions thoroughly before installing, servicing, or operating this equipment.</p> <p>014_020416</p>
	<p>⚠ WARNING</p> <p>This machinery contains sharp blades. Keep hands and body parts clear at all times.</p> <p>037_103114</p>
	<p>⚠ WARNING</p> <p>NEVER put your fingers into the shaver body (the goose-neck, ice chute, or hopper). Serious injury may occur.</p> <p>017_103114</p>
	<p>⚠ WARNING</p> <p>This machine is NOT to be operated by minors.</p> <p>007_010914</p>

IF YOU HAVE ANY QUESTIONS, DOUBTS, PROBLEMS OR CONCERNS AT ANY TIME DURING YOUR RENTAL, STOP AND CALL US AT 833-5-LITTLE, AND SELECT EXT 3 TO SPEAK WITH 24/7 ACTIVE RENTAL SUPPORT

Ice Grinder Motor Switch: Momentary (press-and-hold) switch to turn ice grinder on/off.

Hopper Lid Handle: Used to open/close ice chute, and to safely push ice into ice grinder blades.

Safety Lock Pin: Locks Hopper Lid Handle in closed position when machine is not in use.




WARNING:
SHARP BLADES!
Never reach into
ice chute from
top or inside



→ **SHARP BLADES: NEVER REACH INTO ICE CHUTE FROM TOP OF UNIT OR FROM INSIDE OF UNIT** ←
→ **ALWAYS UNPLUG MACHINE WHEN NOT ACTIVELY BEING USED BY A TRAINED ADULT** ←

PREPARING THE MACHINE & MAKING SNOW CONES



- 1) Remove Safety Lock Pin and raise Hopper Lid.
- 2) Load ice into the Ice Chute.
 - Use either block ice (2-3" in size max) or ice cubes.
 - Harder ice will result in a finer snow, while softer/melting ice will result in a courser snow.
- 3) Close Hopper Lid, keeping hand firmly on Hopper Lid Handle to apply gentle downward pressure.
- 4) Using second hand, press and hold the Ice Grinder Motor Switch until all of the ice has been shaved.
 - **DO NOT OPEN THE ICE CHUTE UNTIL THE MOTOR IS OFF AND SHAVER HEAD HAS STOPPED.**
 - **ONLY ONE TRAINED ADULT OPERATOR SHOULD BE NEAR THE MACHINE WHILE IN USE.**
 - **NEVER PLACE FINGERS OR OTHER BODY PARTS, OR ANY FOREIGN OBJECTS, IN THE ICE CHUTE.**
 - **KEEP HANDS AWAY FROM INSIDE THE UNIT AT ALL TIMES WHEN MACHINE IS PLUGGED IN.**
- 5) Upon completion, ensure that the Hopper Lid Handle is closed, replace the Safety Lock Pin and unplug the machine.
- 6) Scoop ice into the snow cone cups, and pour syrup flavoring onto snow cone cups individually.
 - **NEVER put snow cone syrup into the machine!**

IF YOU HAVE ANY QUESTIONS, DOUBTS, PROBLEMS OR CONCERNS AT ANY TIME DURING YOUR RENTAL, STOP AND CALL US AT 833-5-LITTLE, AND SELECT EXT 3 TO SPEAK WITH 24/7 ACTIVE RENTAL SUPPORT