



Bella's Bouncies Jump Center Lake Villa | 1600 N Milwaukee Ave (Route 83) | Lake Villa, IL 60046

Bella's Bouncies Skate on Grand | 720 E Grand Ave (Route 59) | Fox Lake, IL 60020

Bella's Bouncies Party and Event Rentals | 99 Christopher Way | Fox Lake, IL 60020

www.BellasBouncies.com | 847-546-7000 | bellasbouncies@yahoo.com

Snow-Cone Machine Instructions

1. Fill the gooseneck to within an inch of the top with ice cubes or block ice (no larger than 3" to 4").
2. Toggle the POWER switch to the ON position.
3. While pushing the MOTOR switch, apply downward pressure to the pusher handle. Apply firm and even pressure to make the best snow. Practice will allow you to gauge when to stop pressing. This allows the ice to resettle against the shaver head. Too much pressure will result in snow that is coarse; too little pressure will make the snow mushy.

NEVER ALLOW ANY FOREIGN OR METALLIC OBJECTS AROUND THE SHAVER AREA OF THE SNO-KING. ICE PICKS, SCOOPS, AND DEBRIS THAT MAY BE IN THE ICE OFTEN DAMAGE BLADES AND CREATE A HAZARD TO THE CONSUMER

Machine operates best when plugged in on its own breaker

A 110 outlet is required to operate