

Party Amarillo, LLC

Big Kahuna Slide

ATTENDANTS READ HERE:

1. Two adult attendants must supervise the unit. Do not leave the unit unattended at any time.
2. The attendants must read and understand the safety instructions and are responsible to make all riders aware of the safety rules. Safety of the riders is the responsibility of the attendants.
3. Do not use in high winds, rain, or other unsuitable weather conditions.
4. The inflatable must be securely staked at all times.
5. Only 4 at a time on the inflatable. Riders wait outside the unit for their turn. Do not overcrowd the steps.
6. Group children according to their age, size, and abilities. No infants allowed.
7. Use careful attention to the steps and slide area to avoid overcrowding.
8. Weight limit per person is 200 lbs. One at a time on the slide.
9. Slide down FEET FIRST. Do not dive, jump, or flip onto the slide. Adults may not carry a child down the slide.
10. Do not enter the inflatable through the exit or climb up the slide the wrong direction.
11. Make sure the slide landing area is clear before the next rider goes down the slide.
12. No shoes, silly string, sharp objects, food, gum, confetti, glitter, or pets allowed.
13. Do not climb on the outside of the inflatable.
14. Do not allow the motor to get wet. Keep people away from the blowers and extension cords.
15. Do not allow anyone to participate who is intoxicated, pregnant, or has any other physical limitations, including neck, back, knee or other disabilities that may jeopardize their safety.

TO ASSEMBLE THE GAME:

1. The inflatable is heavy and will take 2-3 strong men to set up the unit. Use caution when lifting.
2. The dimensions are approximately 13'W x 25'L x 18'H. Allow 5' clearance on all sides, including the top.
3. Pick a flat, level location free from overhead obstacles, like electrical lines, or trees, and also away from the vicinity of underground utilities or irrigation.
4. The location must be less than 50 feet from a 20 amp dedicated circuit.
5. Grass is the best surface. If on asphalt, stakes must be drilled into the pavement. The inflatable must be securely anchored at all times.
6. Do not inflate the unit if high winds or rain is present. Watch for severe weather approaching.
7. Unroll the large vinyl roll and locate the blower tubes extending from the unit.
8. Tie one tube securely around the opening of the blower, making sure there are no kinks in the tube.
9. Tie off the other tube.
10. Plug in the blower to a GFI outlet and allow the unit to inflate. Do not plug anything else into the same circuit or it will trip the breaker. (If a generator is used, it must be at least 4000 Watts)
11. Use only the heavy duty extension cords provided by PPP. Do not remove the grounding pin from cord.
12. If the blower is used on a gym floor place a mat under the blower.
13. Immediately stake down the unit. Stakes must be placed at a 90 degree angle straight into the ground.
14. Put the stakes all the way into the ground to prevent a tripping hazard.
15. The blower will run continuously during the event.

16. If inflatable is "soft", check blower tubes for an air leak and check all zippers are closed under the Velcro flaps.

TO TAKE DOWN THE GAME:

1. Clean all debris from the inflatable. Please inform us if the inflatable is dirty or wet.
2. Turn off and untie the blower. Allow the inflatable to deflate. Remove the blower and the stakes.
3. "Square up" each inflatable and fold it into thirds. Roll it very tightly and put straps around the roll.
4. Use extreme caution when handling the inflatable it is heavy and will take 2-3 men to load.
5. Please report any damage to us. All equipment must be returned on time.