

Party Amarillo, LLC

Fun House Maze

ATTENDANTS READ HERE:

1. Two adult attendants must supervise the unit. Do not leave the unit unattended at any time.
2. The attendants must read and understand the safety instructions and are responsible to make all players aware of the safety rules. Safety of the players is the responsibility of the attendants.
3. Deflate immediately if high wind, rain, lightning, or thunder is present or approaching.
4. The inflatable must be securely staked at all times.
5. Only 8 at a time in the inflatable. Do not overcrowd. Riders wait outside the unit for their turn.
6. Group children according to age, size, and abilities. No infants allowed.
7. No running or horse play inside the unit.
8. Do not allow anyone to participate who is intoxicated, pregnant, or has any other physical limitations, including neck, back, knee, or other disabilities that may jeopardize their safety.
9. No shoes, silly string, sharp objects, food, gum, confetti, glitter, water or pets allowed.
10. Do not climb on the outside of the unit.
11. Do not allow the inflatable or motor to get wet. Keep people away from the blowers and extension cords.

TO ASSEMBLE THE GAME:

1. The inflatable is heavy and will take 2 strong men to set up the unit. Use caution when lifting.
2. Dimensions are approximately 20'W x 40'L x 7'H. Allow 5' clearance on all sides, including the top.
3. Pick a flat, level location free from overhead obstacles like electrical lines or trees, and also away from the vicinity of underground utilities or irrigation.
4. The location must be less than 50 feet from a two 20 amp dedicated circuits.
5. Grass is the best surface. The inflatable must be securely anchored at all times.
6. Do not inflate the unit if high wind or rain is present. Watch for severe weather approaching.
7. Unroll the vinyl roll. Locate the blower tubes extending from the unit.
8. Tie the tubes securely around each blower. Make sure there are no kinks in the tubes.
9. Make sure all 6 zippers on the sides of the unit are completely closed.
10. Plug the blowers into a GFI outlet and allow the unit to inflate. Don't plug anything else into the same circuits or it will trip the breaker. (If a generator is used, it must be at least 5000 Watts)
11. Use only the extension cords provided. Do not remove the grounding pin from cord.
12. If the blowers are used on a gym floor, place a mat under the blowers.
13. Immediately anchor the unit by inserting the stakes completely into the ground at a 90 degree angle straight into the ground.
14. The blowers will run continuously during the event.
15. Do not allow anyone in the unit until it is anchored and supervised by a trained attendant.

TO TAKE DOWN THE GAME:

1. Clean all debris from the inflatable. Please inform us if the inflatable is damaged, dirty or wet.
2. Turn off and untie the blowers. Allow the inflatable to deflate. Remove the blowers and the stakes.

3. "Square up" the inflatable and fold it in half and then in half again. Roll tightly and put straps around the roll.
4. Use extreme caution when handling the inflatable. It is heavy and will take 2-3 men to load.