

Party Amarillo, LLC

Extreme Rush

ATTENDANTS READ HERE:

1. Three adult attendants must supervise the unit. (2 in the front and 1 in the back climbing area)
2. Attendants must read and understand the safety instructions and are responsible to make all riders aware of the rules. Safety of the riders is the responsibility of the attendants. Do not leave the unit unattended at any time.
3. Deflate unit immediately if high wind, rain, lightning, or thunder is present or approaching.
4. The inflatable must be securely staked at all times. Do not get the inflatable wet.
5. Only 4 at a time on the inflatable. Do not overcrowd the unit. Weight limit per person is 200 lbs.
6. Group children according to their age, size, and abilities. No infants allowed.
7. One at a time on the slide. Slide down FEET FIRST. Do not dive, jump, or flip onto the slide. Adults may not carry a child down the slide. Do not climb up the slide the wrong direction.
8. Make sure the slide landing area is clear before the next rider goes down the slide
9. Do not enter the inflatable through the exit. Do not climb on the outside of the unit.
10. No shoes, silly string, sharp objects, food, gum, confetti, glitter, or pets allowed.
11. Keep people away from the blowers and extension cords.
12. Do not allow anyone to participate who is intoxicated, pregnant, or has any other physical limitations, including neck, back, knee or other disabilities that may jeopardize their safety.

Generator

FOR SAFETY:

1. **Caution: Do not use the generator indoors.** It is a carbon monoxide hazard.
2. Place the generator at least 15 feet from the blowers so toxic fumes are not sucked into the unit.
3. Always keep children away from the generator.
4. Keep the generator dry. Do not touch it with wet hands. Do not use in wet conditions.
5. The muffler will be hot during and after operation. Use caution when handling.
6. Stop the generator before adding fuel. Use caution! Gasoline is extremely flammable.
7. No smoking while fueling the generator.
8. Do not store the gasoline by the generator. Keep the gasoline away from children.

TO START THE GENERATOR:

1. The generator must be operated and transported in a level position.
2. Fill the generator with provided non ethanol regular gasoline.
3. Check oil to see that it is at the full position. The generator will automatically shut down if the oil level is too low.
4. Make sure all electrical loads are disconnected from the generator before starting.
5. Turn the engine switch to the "on" position.
6. Turn on the fuel switch.
7. Pull out the choke lever. (some models push the choke lever down)
8. Pull the recoil starter.

9. Move the choke lever to the “in” position. (some models move the choke lever to up position)
10. Always keep the circuit breakers in the “on” position.

TO STOP THE GENERATOR:

1. Remove all electrical loads from the generator before turning it off.
2. To stop the generator, turn the engine switch to the “off” position.
3. Use caution because the generator and muffler will be hot.