

Party Amarillo, LLC

Karaoke with Bluetooth

SAFETY INSTRUCTIONS:

1. The Karaoke must always be supervised by an adult.
2. Do not allow food or liquids around the Karaoke.
3. Do not allow rough play or swinging of the Karaoke microphones.
4. Do not pass around the actual CDs. Notebooks of song lists are provided for the singers to select a song.
5. Please make note if any of the CDs are scratched or need to be cleaned.
6. The Karaoke stand can be easily tipped over. Use caution and do not allow wild play.

TO ASSEMBLE THE KARAOKE:

1. The Karaoke system can be transported in a car.
2. The Karaoke must be located in a flat area less than 50' from an electrical outlet.
3. Insert the pedestal into the bottom stand and gently rotate clockwise until tight.
4. Insert the top control unit into the pedestal. Plug in the Karaoke machine.
5. Attach the two microphones to the front of the unit.
6. Connect the 2 speakers to the back of the unit.

TO PLAY A CD+G:

1. Press the FUNCTION button until the screen displays DISC.
2. Insert a CD+G. To see lyrics on screen, you must use a CD+G. Regular CDs will not show lyrics.
3. Make sure the MONITOR switch is ON, if using the small screen. It should be OFF if using a bigger TV or a Bluetooth device.

TO ATTACH THE KARAOKE TO A LARGER TV: (not provided with the rental)

1. Use the cords provided. Attach them to the back of the Karaoke machine in the holes that are labeled AUDIO OUT and VIDEO OUT. Place the other ends of the cords with the corresponding colors that say AUDIO IN and VIDEO IN on the TV.
2. Do not plug in the Karaoke machine until all connections have been made.
3. TV should be on the AUX screen or the proper input channel.

TO USE A BLUETOOTH DEVICE:

1. Press the FUNCTION button repeatedly until the screen displays "BLUETOOTH".
2. Slide the MONITOR switch to OFF. Switch ON the Bluetooth function of your device. This is found in SETTINGS on your iPhone.
3. Select "Singing Machine" to start pairing. If a passcode is needed, enter "0000" to connect.
4. The lyrics to the songs will be seen on your iPhone, but will not be seen on the TV or Monitor.
5. You can download several karaoke apps from the app store on your phone. Several have free songs and songs are available for purchase on your phone. The songs on your iPhone will take some time to download, so it is best to do this ahead of time.

IF USING THE P.A. SYSTEM: (The P.A. system is available for an extra charge)

1. Attach the microphones to the P.A. System.
2. Connect the Karaoke audio output cords (red and white) to the P.A. audio input (red and white).
3. Connect the Karaoke video output cord (yellow) to the TV video input (yellow).