

# Party Amarillo, LLC

## Popcorn Machine

### ATTENDANTS READ HERE:

1. One adult must attend the Popcorn Machine.
2. Do not leave the machine unattended at any time.
3. Do not use the machine in wet or damp conditions.
4. The machine must be properly grounded.
5. The kettle gets very hot. Do not touch it.
6. Do not cover the vent holes on the top of the machine.

### TO MAKE POPCORN:

1. Please provide a table located on a flat area.
2. You will need to provide paper towels, popcorn, oil, bags, and salt.
3. Popcorn premade supplies are available for purchase.
4. The Popcorn Machine can be plugged into a regular 110 household current.
5. Do not use any electrical cords other than those provided by Parties, Picnics, & Promotions.
6. The machine must be properly grounded.
7. Turn on the warmer switch. The light will come on.
8. Turn on the kettle switch. Allow about 2 minutes for the kettle to warm up.
9. Pour  $\frac{3}{4}$  cup popcorn,  $\frac{1}{4}$  cup oil, and  $\frac{1}{2}$  tsp. salt into the kettle.
10. When the popcorn stops popping, turn off the kettle switch.
11. The kettle is hot. Do not touch it.
12. Dump the kettle by turning the handle clockwise about 90 degrees.
13. Be sure the kettle is turned off when not popping corn.

**Machine will be cleaned by Party Amarillo on return, clean out all popped popcorn before returning.**