

Party Amarillo

Soccer Shoot-Out

ATTENDANTS READ HERE:

1. One adult attendant must supervise the unit. Do not leave the unit unattended at any time.
2. The attendant must read and understand the safety instructions and they are responsible to make all players aware of the safety rules. Safety of the players and guests is the responsibility of the attendant.
3. Deflate immediately if high wind, rain, lightning, or thunder is present or approaching.
4. The inflatable must be securely staked at all times.
5. Do not allow anyone to participate who is intoxicated, pregnant, or has any other physical limitations, including neck, back, knee, or other disabilities that may jeopardize their safety.
6. To play the game, participants kick balls into the soccer goal.
7. Keep spectators out of the way of the balls that are being kicked.
8. No shoes, silly string, sharp objects, food, confetti, glitter, or pets allowed.
9. Do not climb on the outside of the inflatable.
10. Do not allow the inflatable or motor to get wet. Keep people away from the blower and extension cords.
11. Do not use any balls other than the ones provided.

TO ASSEMBLE THE GAME:

1. The inflatable will take 1 man to set it up. Use caution when lifting.
2. Dimensions are approximately 13'W x 8'L x 9'H. Allow 5' clearance on all sides, including the top.
3. Protect the kicking area with a barrier to prevent spectators from walking into the kicking lane.
4. Pick a flat, level location free from overhead obstacles like electrical lines or trees, and away from the vicinity of underground utilities or irrigation.
5. Pick a space that will not allow wildly kicked balls to hit a spectator.
6. The location must be less than 50 feet from a 20 amp dedicated circuit.
7. Grass is the best surface. If on asphalt, stakes must be drilled into the pavement. The inflatable must be securely anchored at all times.
8. Do not inflate the unit if high wind or rain is present. Watch for severe weather approaching.
9. Unroll the unit. Locate the blower tube extending from the inflatable.
10. Attach the blower to the back of the unit. It will run continuously.
11. Plug the blower into a GFI outlet and allow the unit to inflate. Do not plug anything else into the same circuit or it will trip the breaker. (If a generator is used, it must be at least 4000 Watts)
12. Use only the extension cords provided. Do not remove the grounding pin from cord.
13. If the blower is used on a gym floor, place a mat under the blower.
14. Immediately anchor the unit by inserting the stakes completely into the ground at a 90 degree angle.

TO TAKE DOWN THE GAME:

1. Clean all debris from the inflatable. Please inform us if the inflatable is damaged, dirty, or wet.
2. Turn off and untie the blower. Allow the inflatable to deflate. Remove the blower and the stakes.
3. "Square up" the inflatable and fold it into thirds. Roll it very tightly and put ties around the roll.
4. Use extreme caution when handling the inflatable. It is heavy and will take 2 men to load.