

Party Amarillo, LLC

T-Ball

ATTENDANTS READ HERE:

1. One adult attendant must supervise the unit. Do not leave the unit unattended at any time.
2. The attendant must read and understand the safety instructions and they are responsible to make all players aware of the safety rules. Safety of the players and guests is the responsibility of the attendant.
3. Deflate immediately if high wind, rain, lightning or thunder is present or approaching.
4. The inflatable must be securely staked at all times.
5. Do not allow anyone to participate who is intoxicated, pregnant, or has any other physical limitations, including neck, back, knee, or other disabilities that may jeopardize their safety.
6. Keep spectators away from the batting zone.
7. A T-Ball stand is provided in case the wind is knocking the ball off the pillar of air.
8. No shoes, silly string, sharp objects, food, confetti, glitter, or pets allowed.
9. Do not climb on the outside of the inflatable.
10. Do not allow the inflatable or motor to get wet. Keep people away from the blower and extension cords.
11. Do not use any balls or bats, other than the ones provided.

TO ASSEMBLE THE GAME:

1. The inflatable will take 1 or 2 men to set it up. Use caution when lifting.
2. Dimensions are approximately 12'W x 16'L x 9'H. Allow 5' clearance on all sides, including the top.
3. Protect the batting zone with a barrier to prevent spectators from injury.
4. Pick a flat, level location free from overhead obstacles like electrical lines or trees, and also away from the vicinity of underground utilities or irrigation.
5. Location should be out of the wind to allow the "floating ball" not to be blown off the pillar of air.
6. The location must be less than 50 feet from a 20 amp dedicated circuit.
7. Grass is the best surface. The inflatable must be securely anchored at all times.
8. Do not inflate the unit if high winds or rain are present. Watch for severe weather approaching.
9. Unroll the unit. Locate the blower tube extending from the inflatable and attach the blower. Verify that there are no kinks in the tube. Tie off the other tube.
10. Plug the blower into a GFI outlet and allow the unit to inflate. Do not plug anything else into the same circuit or it will trip the breaker. (If a generator is used it must be at least 4000 Watts)
11. Use only the extension cords provided. Do not remove the grounding pin from cord.
12. If the blower is used on a gym floor, place a mat under the blower. The blower will run continuously.
13. Immediately anchor the unit by inserting the stakes completely into the ground at a 90 degree angle straight into the ground.

TO TAKE DOWN THE GAME:

1. Clean all debris from the inflatable. Please inform us if the inflatable is damaged, dirty, or wet.
2. Turn off and untie the blower. Allow the inflatable to deflate. Remove the blower and the stakes.
3. "Square up" the inflatable and fold it into thirds. Roll it very tightly and put ties around the roll.
4. Place the bat, balls, and the t-ball stand in the bag provided.
5. Use extreme caution when handling the inflatable. It is heavy and will take 2 men to load.