

Party Amarillo, LLC

Twister

ATTENDANTS READ HERE:

1. One adult attendant must supervise the unit. Do not leave the unit unattended at any time.
2. The attendant must read and understand the safety instructions and they are responsible to make all riders aware of the safety rules. Safety of the riders is the responsibility of the attendant.
3. Deflate immediately if high wind, rain, lightning, or thunder is present or approaching.
4. The inflatable must be securely staked at all times.
5. Only 4 at a time in the inflatable. Do not overcrowd the unit. Riders wait outside the unit for their turn.
6. Weight limit per person is 200 lbs. Group children according to age, size, and abilities. No infants allowed.
7. Do not allow anyone to participate who is intoxicated, pregnant, or has any other physical limitations, including neck, back, knee, or other disabilities that may jeopardize their safety.
8. No shoes, silly string, sharp objects, food, gum, confetti, glitter, or pets allowed.
9. No flips or jumping on the inflatable. Do not allow the inflatable or motor to get wet. Keep people away from the blower and extension cords.

TO ASSEMBLE THE GAME:

1. The inflatable will take 1 man to set up the unit. Use caution when lifting.
2. Dimensions are approximately 13'W X 15'L X 1'H. Allow 5' clearance on all sides, including the top.
3. Pick a flat, level location free from overhead obstacles like electrical lines or trees, and also away from the vicinity of underground utilities or irrigation.
4. The location must be less than 50 feet from a 20 amp dedicated circuit.
5. Grass is the best surface. The inflatable must be securely anchored at all times.
6. Do not inflate the unit if high wind or rain is present. Watch for severe weather approaching.
7. Unroll the vinyl roll and locate the blower tubes extending from the unit.
8. Tie one tube securely around the blower. Make sure there are no kinks in the tube.
9. Tie off the other tube. The blower will run continuously during the event.
10. Plug the blower into a GFI outlet and allow the unit to inflate. Do not plug anything else into the same circuit or it will trip the breaker. (If a generator is used, it must be at least 4000 Watts)
11. Use only the electric cords provided. Do not remove the grounding pin from cord.
12. If the blower is used on a gym floor, place a mat under the blower.
13. Immediately anchor the unit by inserting the stakes completely into the ground at a 90 degree angle straight into the ground.
14. Do not allow anyone on the unit until it is anchored and supervised by a trained attendant.

TO TAKE DOWN THE GAME:

1. Clean all debris from the inflatable. Please inform us if the inflatable is damaged, dirty or wet.
2. Turn off and untie the blower. Allow the inflatable to deflate. Remove the blower and the stakes.
3. "Square up" the inflatable and fold it into thirds. Roll it very tightly and put ties around the roll.
4. Use extreme caution when handling the inflatable. It is heavy and will take 1 strong man to load.