

Taking Down a Moonwalk

Step 1: Inspect & Clean

Before deflating the unit, complete a quick walk around the outside and inspect for any damage or unusual dirt or debris. Then climb inside and inspect the inside while you clean.

Sweep the unit using a soft-bristle broom only. Sweep along the stripes on the floor, pushing debris out the vent holes in the corners of the unit.

Use a handheld vacuum will clean out those hard to reach crevices where the floor is seamed together. A crevice tool may be used as an option if you don't have a hand vacuum.

Step 2: Deflate & Unsecure

Making sure everything is out of the unit before you turn it off, turn off the blower and unhook the straps securing the blower tube to the blower.

Release the straps on the other blower tube to allow air to escape.

Pull up the stakes all around the unit or unhook sandbags and pack them up.

Walk (in sock feet) from front to back on the unit, moving any remaining air toward the blower tubes.

Step 3: Folding

A proper fold and tight roll are critical to protecting the unit from damage during transportation.

Fold the sides in to the center, flattening them out as much as possible.

Now, take the top back corner and fold it back out to the side of the unit.

Grab the other top back corner from the other wall and pull it back over to the side to completely flatten the back of the unit.

Perform the same fold to the front of the unit. If there is a decorative element on the front of the unit, pull it straight back.

Pull back the corners on each side of the front to flatten it, and then fold in the base of the unit all the way around, folding in the safety step.

Fold one side in to the middle followed by folding the other side overlapping the first.

Step 4: Rolling

Start your roll from the front of the unit. Keep pushing and flattening the unit as you go to keep it tight. If possible, have someone walk in front of your roll to move the air to the end of the unit.

Keep pushing and flattening the roll as you go. It helps to have someone walk on the roll right in front of you.

Slide the straps under the unit and run the straps thru the D-ring on the other end of the straps and pull tight.

Loop the end of the strap around and tie in a slip knot.

Tip the unit up onto the end of the roll and place a hand truck under it for movement.