

Party Amarillo, LLC

Bungee Sports Challenge

ATTENDANTS READ HERE:

1. One adult attendant must supervise the unit. Do not leave the unit unattended at any time.
2. The attendant must read and understand the safety instructions and they are responsible to make all riders aware of the safety rules. Safety of the riders is the responsibility of the attendant.
3. Deflate immediately if high wind, rain, lightning or thunder is present or approaching.
4. The inflatable must be securely staked at all times.
5. Bungee harnesses must be securely fastened to the bungee cord. Check the bungee cord for any kinks, bends, or tears during the event. If the integrity of the cord is compromised, do not use it.
6. Only 2 at a time on the inflatable. Do not overcrowd the unit. Do not allow the attendant on the inflatable.
7. Weight limit per person is 200 lbs. Group participants according to age, size, and abilities.
8. Do not allow anyone to participate who is intoxicated, pregnant, or has any other physical limitations, including neck, back, knee, or other disabilities that may jeopardize their safety.
9. Participants pull against each other to dunk basketballs. The first one to dunk 3 basketballs will win.
10. No shoes, silly string, sharp objects, food, confetti, glitter, or pets allowed.
11. Do not climb on the outside of the inflatable or sit on the sides of the inflatable.
12. Do not allow the inflatable or motor to get wet. Keep people away from the blower and extension cords.

TO ASSEMBLE THE GAME:

1. The inflatable is heavy and will take 2 strong men to set up the unit. Use caution when lifting.
2. Dimensions are approximately 14.5'W x 30'L x 10.5'H. Allow 5' clearance on all sides, including the top.
3. Pick a flat, level location free from overhead obstacles like electrical lines or trees, and also away from the vicinity of underground utilities or irrigation.
4. The location must be less than 50 feet from a 20 amp dedicated circuit.
5. Grass is the best surface. The inflatable must be securely anchored at all times.
6. Do not inflate the unit if high winds or rain is present. Watch for severe weather approaching.
7. Unroll the vinyl roll and locate the blower tubes extending from the unit.
8. Tie one tube securely around the blower. Make sure there are no kinks in the tube.
9. Tie off the other tube and make sure all zippers are closed under the Velcro flaps.
10. Plug the blower into a GFI outlet and allow the unit to inflate. Do not plug anything else into the same circuit or it will trip the breaker. (If a generator is used, it must be at least 4000 Watts)
11. Use only the extension cords provided. Do not remove the grounding pin from cord.
12. If the blower is used on a gym floor, place a mat under the blower.
13. Immediately anchor the unit by inserting the stakes completely into the ground at a 90 degree angle straight into the ground.
14. The blower will run continuously during the event.

TO TAKE DOWN THE GAME:

1. Clean all debris from the inflatable. Please inform us if the inflatable is damaged, dirty or wet.
2. Turn off and untie the blower. Allow the inflatable to deflate. Remove the blower and the stakes.
3. "Square up" the inflatable and fold it into thirds. Roll it very tightly and put straps around the roll.
4. Use extreme caution when handling the inflatable. It is heavy and will take 2-3 men to load.